

Toledo


TOLEDO/BL

PART LIST


KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	6	1	Mechanism	11	1	Backrest Screw
2	1	Base	7	6	Mechanism Screw	12	1	Backrest
3	1	Seat Post	8	1	Backrest Post	13	1	Allen Wrench
4	1	Seat Post Cover	9	2	Backrest Bolt + Washer			,
5	1	Seat	10	1	Backrest Post Bellow			













ATTENTION

- THIS ASSEMBLY INSTRUCTION IS ONLY FOR ASSEMBLING
 THE CHAIR. THE CHAIR DRAWING MAY BE DIFFERENT FROM
- CHAIR APPEARANCE.
 2. SOME SCREWS MAY PREASSEMBLED, ASSEMBLERS CAN
- IGNORE THE STEP.

 3. REMOVE ALL ITEMS FROM THE CARTON. VERIFY ALL PIECES BEFORE ASSEMBLY.

- PREVENTIVE MAINTENANCE AND WARNING!

 IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS. DISPOSE OF PACKAGING PROPERLY.
- FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

 EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.

TOLEDO